

OWL / Electrisave / Electricity Display Devices - safety and care instructions

Warning

To ensure you use your product correctly and safely, read these warnings and the User Manual before using the product. These warnings provide safety information and should be observed at all times.

When fitting sensors if in any doubt always consult a qualified electrician


Warnings

- For Owls – follow the installation instructions on the web site. There is a video guide to help you with installation <http://www.theowl.com/index.php?page=installation>
- Do not attempt to install the device yourself if you have a three phase supply (see accompanying information sheet 'Is my electricity meter single phase or three phase?').
- Do not attempt to repair the product yourself – this should be done by the manufacturer.
- Take precautions when handling all battery types. They can cause injuries, burns, or property damage as a result of contact with conducting materials, heat, corrosive materials or explosives. Remove the batteries before storing the product for long periods of time.
- Do not immerse the device in water.
- Do not, under any circumstances, touch the exposed electronic circuitry of the device, as there is a danger of electric shock should it become exposed.
- Take special care when handling a damaged LCD display, as liquid crystals can be harmful to your health.
- Do not use or store this device, including the remote sensor, in locations that may adversely effect the product such as rain, snow, desert, and magnetic fields.
- Do not use this device in aircrafts or hospitals. The use of radio frequency products can cause malfunctions in the control devices or other equipment.
- Do not subject the product to impact or shock.
- When disposing of this product, do so in accordance with your local waste disposal regulations.

Safety precautions

Please observe the following safety precautions when setting up and using this product.

- LCD panel – the LCD panel is made of glass, and may break if the unit is dropped or impacted.
- Heat sources – keep the product away from heat sources such as radiators, stoves, heaters and other heat generating products.
- Water and moisture – do not use the product in or near water of high moisture areas such as a bathroom.
- Power source – the product may be susceptible to power surges, and the Current Sensor cable should be disconnected from the Transmitter during severe storms.



To ensure you receive the maximum benefit from using the product, please observe the following guidelines:

- Cleaning – disconnect the current Sensor and remove the batteries from the Remote Transmitter and the Main Unit Receiver before cleaning. Use a damp cloth. Do not use liquid cleaning agents, benzene, thinner, or aerosols.
- Ventilation – the vents and other openings are designed for ventilation and should not be blocked or covered. Blocking the vents can cause the product to overheat and can damage the unit.
- Repair – do not attempt to repair the product or modify the circuitry by yourself. Contact the retailer or a qualified repairman if the product requires servicing. Only use replacement parts that are recommended by the manufacturer.
- Do not scratch hard objects against the LCD display as this may cause damage.

For further information, please get in touch with the Energy Team on Tel: 01926 41 4114 or 01926 47 6623.